



Fig. 1



Fig. 2



Fig. 3



Fig. 4



Fig. 5

# Instructions for Installing Pole-Wrap®

**Step 1:** Measure the length of the pole to be covered. Roll up Pole-Wrap and mark your length measurement with a pencil. Cut the roll on your mark with a fine tooth saw (see Fig. 1).

**Step 2:** Take time to flex each panel of Pole-Wrap so that it will conform to the pole surface. Folding panels against a sharp table edge works well here.

**Step 3:** Using a utility knife, cut the width along a v-groove so Pole-Wrap just overlaps when test wrapped around the pole (see Fig. 2). The adhesive applied later will take up space, eliminating this overlap and produce an invisible seam.

**Step 4:** Apply any quality brand of construction adhesive around the pole using a caulking gun. Space ¼" beads around the pole about every 10 inches. Add two full length vertical beads to hold the Pole-Wrap ends evenly together (see Fig. 3).

**Step 5:** After the adhesive is applied, promptly wrap Pole-Wrap around the pole. Start with the inside middle and pull the ends around toward you until they meet (see Fig. 3). Wrap masking tape around the outside of the finished pole to hold Pole-Wrap in place until the adhesive is dry.

**Step 6:** (Steps 6-8 for optional cap and base) Start with the bottom layer of the base and apply construction adhesive to the underside of both halves. Position the halves around the pole and wrap masking tape around the perimeter to hold the halves firmly together (see Fig. 4). Do the same with the top layer of the base. Press both layers firmly against the carpet or bare floor.

**Step 7:** Position the halves for the cap (same as top layer of base, but inverted) around the pole and tape the perimeter to hold the two halves together (see Fig. 4). Apply construction adhesive to the top side of both halves.

**Step 8:** Slide the taped cap unit up along the pole and press it firmly against the ceiling. Use two strips of masking tape (blue for painted surfaces) to hold the cap unit in place (see Fig. 5).

**Step 9:** After the adhesive is dry, remove all of the tape from the cap, base and Pole-Wrap. Trim away any excess adhesive with a utility knife. Paint or stain as you would any other wood surface. Three light coats of polyurethane looks great.

Things you will need:

1. Tape Measure
2. Pencil
3. Fine Tooth Saw
4. Utility Knife
5. Caulking Gun
6. Tube Construction Adhesive
7. Masking Tape



[www.polewrap.com](http://www.polewrap.com)